

Equipment

- ☐ Agnav GUIA
- ☐ Flow Switch
- ☐ Spray Relay
- ☐ Spray Valve


Agnav GUIA

- ☐ Detects Position of Aircraft
- ☐ Records Aircraft Position
- ☐ Records Spray Status
- ☐ Contains Spray Polygon
- ☐ Turn ON Spray System
- ☐ Turn OFF Spray System









GUIA Settings

□ Lag Time

The time required for the GUIA to compute its location from the satellite data

☐ Relay ON Time

The time required the spray to begin exiting the spray boom following turning the switch ON.

☐ Relay OFF Time

The time required the spray to stop exiting the spray boom following turning the switch OFF.

No Settings Made



Lag Set at 0.7 sec



Relay ON Set




Relay ON and Relay OFF Set



Saw Tooth Edge: Improper or no settings









Questions?

